

Dexon

Tecnologias Digitais

Guia de Instalação do Leitor e Gravador de Cartões *e-Smart*

Sistema Operacional Linux Serial Port

- Realiza operações de forma rápida e segura.
- É conectado diretamente em computadores e servidores através de um Cabo USB.
- Atende todos os requisitos da Certificação Digital.
- É ideal para entidades bancarias e serviços de empresas na internet

```
=====
=      Alcornmicro Smart card reader      =
=      Linux TARBALL Package Release Note  =
=====
```

Step1. Install pcsc-lite

```
$ PKG_CONFIG_PATH=$PKG_CONFIG_PATH:/usr/local/lib/pkgconfig;export
PKG_CONFIG_PATH
```

```
$ tar xjf pcsc-lite-1.7.4.tar.bz2
# cd pcsc-lite-1.7.4
# ./configure
# make
# make install          (Login as a root to install driver)
```

Step2. Install ccid driver

```
# tar xjf ccid-1.4.5-alcor.tar.bz2
# cd ccid-1.4.5-alcor
# ./configure --enable-twinserial --disable-libusb
# make
# make install          (Login as a root to install driver)
```

configuring the driver for the serial reader
~~~~~

You have to create or edit the file /etc/reader.conf. The file should contain something like:

```
# AlocrMicro reader with serial communication
# - reader is the reader name. It is needed for multi-slot readers.
# Possible reader values are: AU9540, AU9528,
# AU9540 (default value)
# example: /dev/ttyS0:AU9540
#FRIENDLYNAME      "Generic serial"
#DEVICENAME        /dev/ttySn[:reader]
#LIBPATH           TARGET
#CHANNELID         n
```

```
# gedit /usr/local/etc/reader.conf.d/libccidtwin
#AU9540
FRIENDLYNAME      "Generic serial"
DEVICENAME        /dev/ttyS1:AU9540
LIBPATH           /usr/local/lib/pcsc/drivers/serial/libccidtwin.so
CHANNELID         1
```

```
or
#AU9528
FRIENDLYNAME      "Generic serial"
DEVICENAME        /dev/ttyS1:AU9528
LIBPATH           /usr/local/lib/pcsc/drivers/serial/libccidtwin.so
CHANNELID         2
```

note: you can test it follow these steps

```
# cd pcsc-lite-1.7.2/doc/example
# ./pcsc_demo
```